

Communication Extension Module **Z-COM** PLC Communication Data List

Thank you for purchasing this RKC product. In order to achieve maximum performance and ensure proper operation of your new instrument, carefully read all the instructions in this manual. Please place this manual in a convenient location for easy reference.

This manual describes the PLC communication data of the Z-COM. For the host communication, the installation, the detail handling procedures and various function settings, please read if necessary the following separate manuals.

- Z-COM Installation Manual (IMS01T05-E□): Enclosed with Z-COM
- Z-COM Host Communication Quick Instruction Manual (IMS01T09-E□): Enclosed with Z-COM
- Z-COM PLC Communication Quick Instruction Manual (IMS01T14-E□): Enclosed with Z-COM
- Z-COM Instruction Manual (IMS01T22-E□): Separate (Download or sold separately)
- Z-COM Host Communication Instruction Manual (IMS01T23-E□): Separate (Download or sold separately)
- Z-TIO INSTRUCTION MANUAL (IMS01T01-E□): Enclosed with Z-TIO
- Z-TIO Host Communication Quick Instruction Manual (IMS01T02-E□): Enclosed with Z-TIO
- SRZ Instruction Manual (IMS01T04-E□): Separate (Download or sold separately)
- Z-DIO INSTRUCTION MANUAL (IMS01T03-E□): Enclosed with Z-DIO

The manuals can be downloaded from our website:
URL: http://www.rkcinst.com/english/manual_load.htm

1. EXPLANATION OF DATA MAP ITEMS

The data that can be communicated by the PLC and SRZ unit is compiled in the PLC communication data map.

Name:	Name of communication data	Attribute:	RO: At the time of monitor request bit "1," SRZ unit writes in data to the PLC. (PLC ← SRZ)
Register address:	A register address of communication data in PLC communication 16 CH: Register address of 16-channel specification 32 CH: Register address of 32-channel specification 48 CH: Register address of 48-channel specification 64 CH: Register address of 64-channel specification	RAW: At the time of setting request bit "1," SRZ unit read out data from the PLC. At the time of monitor request bit "1," SRZ unit writes in data to the PLC. (PLC ↔ SRZ)	
Structure:	U: Data for each SRZ unit M: Data for each module C: Data for each channel ^{1,2}	Data range: Read or write range of communication data	
	Register addresses in this manual are those assigned when the PLC communication environment is set as follows. • Register type: 0 (MITSUBISHI PLC MELSEC series: D register) • Register start number: 1000	Number of data: This is the maximum number per communication data that can be handled by one SRZ unit. The total number of communication data: 16-channel specification: 524 items 32-channel specification: 1036 items 48-channel specification: 1548 items 64-channel specification: 2060 items	
	If you are using the OMRON PLC SYSMAC Series or a different register type, substitute the register you are using in the above.		
	¹ On a Z-TIO module (2-channel type), the communication data of CH3 and CH4 becomes invalid.		
	² ♣: Parameters only used for heat/cool control or position proportioning control, therefore data for CH2 and CH4 of Z-TIO modules are unused. [Read is possible "0," but the result of Write is disregarded.]		

The SRZ unit occupies a number of PLC registers equal to the maximum number of data items. Even if there are fewer functional modules (Z-TIO/Z-DIO modules) connected to the Z-COM module, or there are unused communication items, the number of registers occupied does not change. If functional modules (Z-TIO/Z-DIO modules) are not connected or there are unused data items, "0" is sent.

Factory set value: Factory set value of communication data

2. DATA MAP

- | | |
|---|---|
| <ul style="list-style-type: none"> • 16-channel specification
System data (monitor item): D01000 to D01007
Monitor group: D01010 to D01150
Setting group: D01008, D01009 and D01151 to D01523 | <ul style="list-style-type: none"> • 48-channel specification
System data (monitor item): D01000 to D01007
Monitor group: D01010 to D01430
Setting group: D01008, D01009 and D01431 to D02547 |
| <ul style="list-style-type: none"> • 32-channel specification
System data (monitor item): D01000 to D01007
Monitor group: D01010 to D01290
Setting group: D01008, D01009 and D01291 to D02035 | <ul style="list-style-type: none"> • 64-channel specification
System data (monitor item): D01000 to D01007
Monitor group: D01010 to D01570
Setting group: D01008, D01009 and D01571 to D03059 |

Name	Register address				Structure	Attribute	Data range	Number of data	Factory set value
	16 CH	32 CH	48 CH	64 CH					
System communication state	D01000	D01000	D01000	D01000	U	RO	Bit data b0: Data collection condition b1 to b15: Unused Data 0: Before data collection is completed 1: Data collection is completed [Decimal number: 0, 1]	1	—
SRZ normal communication flag	D01001	D01001	D01001	D01001	U	RO	0/1 transfer (For communication checking) "0" and "1" are repeated for each communication period.	1	—
—	D01002	D01002	D01002	D01002	—	—	Internal processing Do not use the register address	1	—
—	D01003	D01003	D01003	D01003	—	—	Internal processing Do not use the register address	1	—
PLC communication error code	D01004	D01004	D01004	D01004	U	RO	Bit data b0: PLC register read/write error b1: Slave communication timeout b2: Unused b3: Internal communication error b4: Master communication timeout b5 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 31]	1	—

Name	Register address				Structure	Attribute	Data range	Number of data	Factory set value
	16 CH	32 CH	48 CH	64 CH					
Unit recognition flag	D01005	D01005	D01005	D01005	U	RO	Bit data b0: SRZ unit 1 b1: SRZ unit 2 b2: SRZ unit 3 b3: SRZ unit 4 b4 to b15: Unused Data 0: No unit exists 1: Unit exists [Decimal number: 0 to 15]	1	—
Monitor for the number of connected modules	D01006	D01006	D01006	D01006	U	RO	0 to 31	1	—
Number of valid groups	D01007	D01007	D01007	D01007	U	RO	0 to 128	1	—
Request command	D01008	D01008	D01008	D01008	U	R/W	Bit data b0: Setting request bit b1: Monitor request bit Data 0: OFF 1: ON [Decimal number: 0 to 3]	1	0
Setting item communication state	D01009	D01009	D01009	D01009	U	RO	Bit data b0: Setting error b1: Setting completed bit b2: Monitor completed bit Data 0: OFF 1: ON [Decimal number: 0 to 7]	1	—
Measured value (PV)	D01010 to D01025	D01010 to D01041	D01010 to D01057	D01010 to D01073	C	RO	Input scale low to Input scale high	16CH: 16 32CH: 32 48CH: 48 64CH: 64	—
Comprehensive event state	D01026 to D01041	D01042 to D01073	D01058 to D01105	D01074 to D01137	C	RO	Bit data b0: Event 1 b1: Event 2 b2: Event 3 b3: Event 4 b4: Heater break alarm state b5: Temperature rise completion b6: Burnout b7 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 127]	16CH: 16 32CH: 32 48CH: 48 64CH: 64	—
Operation mode state monitor	D01042 to D01057	D01074 to D01105	D01106 to D01153	D01138 to D01201	C	RO	Bit data b0: Control STOP b1: Control RUN b2: Manual mode b3: Remote mode b4 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 15]	16CH: 16 32CH: 32 48CH: 48 64CH: 64	—
Manipulated output value (MV) monitor [heat-side] ♣	D01058 to D01073	D01106 to D01137	D01154 to D01201	D01202 to D01265	C	RO	PID control or heat/cool PID control: -5.0 to +105.0 % Position proportioning control (with FBR input): 0.0 to 100.0 %	16CH: 16 32CH: 32 48CH: 48 64CH: 64	—
Manipulated output value (MV) monitor [cool-side] ♣	D01074 to D01089	D01138 to D01169	D01202 to D01249	D01266 to D01329	C	RO	-5.0 to +105.0 %	16CH: 16 32CH: 32 48CH: 48 64CH: 64	—
Current transformer (CT) input value monitor	D01090 to D01105	D01170 to D01201	D01250 to D01297	D01330 to D01393	C	RO	CTL-6-P-N: 0.0 to 30.0 A CTL-12-S56-10L-N: 0.0 to 100.0 A	16CH: 16 32CH: 32 48CH: 48 64CH: 64	—
Set value (SV) monitor	D01106 to D01121	D01202 to D01233	D01298 to D01345	D01394 to D01457	C	RO	Setting limiter (low) to Setting limiter (high)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	—
Remote setting (RS) input value monitor	D01122 to D01137	D01234 to D01265	D01346 to D01393	D01458 to D01521	C	RO	Setting limiter (low) to Setting limiter (high)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	—
Output state monitor	D01138 to D01141	D01266 to D01273	D01394 to D01405	D01522 to D01537	M	RO	Bit data b0: OUT1 b1: OUT2 b2: OUT3 b3: OUT4 b4 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 15]	16CH: 4 32CH: 8 48CH: 12 64CH: 16	—
Digital input (DI) state 1	D01142 to D01145	D01274 to D01281	D01406 to D01417	D01538 to D01553	M	RO	Bit data b0: DI1 b1: DI2 b2: DI3 b3: DI4 b4: DI5 b5: DI6 b6: DI7 b7: DI8 b8 to b15: Unused Data 0: Contact open 1: Contact closed [Decimal number: 0 to 255]	16CH: 4 32CH: 8 48CH: 12 64CH: 16	—

♣: Parameters only used for heat/cool control or position proportioning control, therefore data for CH2 and CH4 of Z-TIO modules are unused.

Name	Register address				Structure	Attribute	Data range	Number of data	Factory set value
	16 CH	32 CH	48 CH	64 CH					
Digital output (DO) state 1	D01146 to D01149	D01282 to D01289	D01418 to D01429	D01554 to D01569	M	RO	Bit data b0: DO1 b1: DO2 b2: DO3 b3: DO4 b4: DO5 b5: DO6 b6: DO7 b7: DO8 b8 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 255]	16CH: 4 32CH: 8 48CH: 12 64CH: 16	—
Error code	D01150	D01290	D01430	D01570	U	RO	Bit data b0: SRAM error*/Adjustment data error b1: Data back-up error b2: A/D conversion error b3: Unused b4: Unused b5: Logic output data error b6: Stack overflow * b7 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 255] * These are error code only of the Z-COM module	1	—
PID/AT transfer	D01151 to D01166	D01291 to D01322	D01431 to D01478	D01571 to D01634	C	R/W	0: PID control 1: Autotuning (AT)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	0
Auto/Manual transfer	D01167 to D01182	D01323 to D01354	D01479 to D01526	D01635 to D01698	C	R/W	0: Auto mode 1: Manual mode	16CH: 16 32CH: 32 48CH: 48 64CH: 64	0
Event 1 set value (EV1)	D01183 to D01198	D01355 to D01386	D01527 to D01574	D01699 to D01762	C	R/W	Deviation action, Deviation action between channels, Temperature rise completion range *: -Input span to +Input span * When temperature rise completion is selected at Event 3 action type.	16CH: 16 32CH: 32 48CH: 48 64CH: 64	50
Event 2 set value (EV2)	D01199 to D01214	D01387 to D01418	D01575 to D01622	D01763 to D01826	C	R/W	Process action, SV action: Input scale low to Input scale high	16CH: 16 32CH: 32 48CH: 48 64CH: 64	50
Event 3 set value (EV3)	D01215 to D01230	D01419 to D01450	D01623 to D01670	D01827 to D01890	C	R/W	MV action: -5.0 to +105.0 %	16CH: 16 32CH: 32 48CH: 48 64CH: 64	50
Event 4 set value (EV4)	D01231 to D01246	D01451 to D01482	D01671 to D01718	D01891 to D01954	C	R/W		16CH: 16 32CH: 32 48CH: 48 64CH: 64	50
Set value (SV)	D01247 to D01262	D01483 to D01514	D01719 to D01766	D01955 to D02018	C	R/W	Setting limiter (low) to Setting limiter (high)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	TC/RTD: 0 °C [°F] V/I: 0.0 %
Proportional band [heat-side] *	D01263 to D01278	D01515 to D01546	D01767 to D01814	D02019 to D02082	C	R/W	TC/RTD inputs: 0 (0.0) to Input span (Unit: °C [°F]) Voltage (V)/current (I) inputs: 0.0 to 1000.0 % of Input span 0 (0.0): ON/OFF action	16CH: 16 32CH: 32 48CH: 48 64CH: 64	TC/RTD: 30 V/I: 30.0
Integral time [heat-side] *	D01279 to D01294	D01547 to D01578	D01815 to D01862	D02083 to D02146	C	R/W	PID control or heat/cool PID control: 0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PD action) Position proportioning control: 1 to 3600 seconds or 0.1 to 1999.9 seconds	16CH: 16 32CH: 32 48CH: 48 64CH: 64	240
Derivative time [heat-side] *	D01295 to D01310	D01579 to D01610	D01863 to D01910	D02147 to D02210	C	R/W	0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PI action)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	60
Proportional band [cool-side] *	D01311 to D01326	D01611 to D01642	D01911 to D01958	D02211 to D02274	C	R/W	TC/RTD inputs: 1 (0.1) to Input span (Unit: °C [°F]) Voltage (V)/current (I) inputs: 0.1 to 1000.0 % of Input span	16CH: 16 32CH: 32 48CH: 48 64CH: 64	TC/RTD: 30 V/I: 30.0
Integral time [cool-side] *	D01327 to D01342	D01643 to D01674	D01959 to D02006	D02275 to D02338	C	R/W	0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PD action)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	240
Derivative time [cool-side] *	D01343 to D01358	D01675 to D01706	D02007 to D02054	D02339 to D02402	C	R/W	0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PI action)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	60
Control response parameter *	D01359 to D01374	D01707 to D01738	D02055 to D02102	D02403 to D02466	C	R/W	0: Slow 1: Medium 2: Fast When the P or PD action is selected, this setting becomes invalid.	16CH: 16 32CH: 32 48CH: 48 64CH: 64	PID control, Position proportioning control: 0 Heat/cool PID control: 2

*: Parameters only used for heat/cool control or position proportioning control, therefore data for CH2 and CH4 of Z-TIO modules are unused.

Name	Register address				Structure	Attribute	Data range	Number of data	Factory set value
	16 CH	32 CH	48 CH	64 CH					
Overlap/Deadband *	D01375 to D01390	D01739 to D01770	D02103 to D02150	D02467 to D02530	C	R/W	TC/RTD inputs: -Input span to +Input span (Unit: °C [°F]) Voltage (V)/current (I) inputs: -100.0 to +100.0 % of Input span	16CH: 16 32CH: 32 48CH: 48 64CH: 64	0
Setting change rate limiter (up)	D01391 to D01406	D01771 to D01802	D02151 to D02198	D02531 to D02594	C	R/W	0 (0.0) to Input span/unit time 0 (0.0): Unused	16CH: 16 32CH: 32 48CH: 48 64CH: 64	0 (0.0)
Setting change rate limiter (down)	D01407 to D01422	D01803 to D01834	D02199 to D02246	D02595 to D02658	C	R/W	Unit time: 60 seconds (factory set value)		0 (0.0)
Heater break alarm (HBA) set value	D01423 to D01438	D01835 to D01866	D02247 to D02294	D02659 to D02722	C	R/W	When CT is CTL-6-P-N: 0.0 to 30.0 A (0.0: Not used) When CT is CTL-12-S56-10L-N: 0.0 to 100.0 A (0.0: Not used)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	0.0
Heater break determination point	D01439 to D01454	D01867 to D01898	D02295 to D02342	D02723 to D02786	C	R/W	0.0 to 100.0 % of HBA set value (0.0: Heater break determination is invalid)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	30.0
Heater melting determination point	D01455 to D01470	D01899 to D01930	D02343 to D02390	D02787 to D02850	C	R/W	0.0 to 100.0 % of HBA set value (0.0: Heater melting determination is invalid)	16CH: 16 32CH: 32 48CH: 48 64CH: 64	30.0
PV bias	D01471 to D01486	D01931 to D01962	D02391 to D02438	D02851 to D02914	C	R/W	-Input span to +Input span	16CH: 16 32CH: 32 48CH: 48 64CH: 64	0
Manual manipulated output value *	D01487 to D01502	D01963 to D01994	D02439 to D02486	D02915 to D02978	C	R/W	PID control: Output limiter (low) to Output limiter (high) Heat/cool PID control: -Cool-side output limiter (high) to +Heat-side output limiter (high) Position proportioning control (with FBR input): Output limiter (low) to Output limiter (high) Position proportioning control (without FBR input): 0: Close-side output OFF, Open-side output OFF 1: Close-side output ON, Open-side output OFF 2: Close-side output OFF, Open-side output ON	16CH: 16 32CH: 32 48CH: 48 64CH: 64	0.0
Operation mode	D01503 to D01518	D01995 to D02026	D02487 to D02534	D02979 to D03042	C	R/W	0: Unused 1: Monitor 2: Monitor + Event function 3: Control	16CH: 16 32CH: 32 48CH: 48 64CH: 64	3
DO manual output 1	D01519 to D01522	D02027 to D02034	D02535 to D02546	D03043 to D03058	M	R/W	Bit data b0: DO1 manual output b1: DO2 manual output b2: DO3 manual output b3: DO4 manual output b4: DO5 manual output b5: DO6 manual output b6: DO7 manual output b7: DO8 manual output b8 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 255]	16CH: 4 32CH: 8 48CH: 12 64CH: 16	0
RUN/STOP transfer (Each unit)	D01523	D02035	D02547	D03059	U	R/W	0: STOP (Control stop) 1: RUN (Control start)		1 0

*: Parameters only used for heat/cool control or position proportioning control, therefore data for CH2 and CH4 of Z-TIO modules are unused.

☞ The host computer is used to set communication data (engineering data, operation data, etc.) of functional modules (Z-TIO/Z-DIO modules) that cannot be set by PLC communication.

For the communication data, see **Z-COM Host Communication Instruction Manual (IMS01T23-ED)** or **SRZ Instruction Manual (IMS01T04-ED)**.

The name of each programmable controller (PLC) means the products of each manufacturer. Company names and product names used in this manual are the trademarks or registered trademarks of the respective companies.

RKC RKC INSTRUMENT INC. The first edition: DEC. 2006 [IMQ00]
The second edition: AUG. 2008 [IMQ00]
HEADQUARTERS: 16-6, KUGAHARA 5-CHOME, OHTA-KU TOKYO 146-8515 JAPAN
PHONE: 03-3751-9799 (+81 3 3751 9799) E-mail: info@rkinst.co.jp
FAX: 03-3751-8585 (+81 3 3751 8585) AUG. 2008